




GFMS Integrator

Key Systems, Inc.'s GFMS Integrator is a secure platform for two way data sharing between GFMS™ and your existing facility management software. This new release is a software only update available to new and existing GFMS™ customers alike.

Our new platform removes the need to manage GFMS™ as a secondary software interface. GFMS Integrator provides access to GFMS alarms, user and group information, key transactions, and more. You are also able to add and edit data within GFMS through GFMS Integrator. This would include adding users to GFMS and changing user data (like updating a Badge ID). Avoid updates to redundant user data and eliminate physical relays to your facilities monitoring systems.



GFMS Symmetry Driver Features

GFMS alarms appear in Symmetry Alarm Monitor

- Alarms will be sorted by device (SAM)
- Alarms can be acknowledged in Symmetry
- Alarms will display Type, Associated User/Key, and the Date and Time the alarm occurred

Symmetry user modifications update to GFMS in real-time

- Use Symmetry to update user ID information and scheduling to GFMS
- User add/deletes are synced directly to GFMS

Requirements & Specifications

Key Systems, Inc. combines the integration capabilities of the Symmetry Data Connect™ service available to AMAG customers with our own integration module, GFMS Integrator. This provides a rich, stable environment for data sharing between the two software systems.

GFMS Requirements:

- GFMS v3.0 or greater

AMAG Requirements:

- Certified through version 9.1



SYMMETRY™ GLOBAL

The GFMS Integrator Symmetry Driver is built on top of the functionality provided by the GFMS Integrator. It interfaces with the AMAG Symmetry Data Connect platform, sharing data between both and Symmetry through configurable features set by the customer.

